

Splice Kit (Connecting cables together) Instructions



This product must be installed by a qualified electrician in accordance with all national and local electrical and construction codes.
Failure to comply with the installation instructions can result in serious injury or death.



1 Inside the kit



(a). Open the kit and make sure you have:
1 x Single section of cable
2 x Heat shrink pre cut at 150mm.

NOTE: Section of cable will be pre-crimped.

2 Crimping the cables together



(a). Slide heat shrink sleeve over existing cable.

(b). Check that both cables face the same way, with the printed cable writing at the rear.

NOTE: This will assure the lamp holder is facing the correct direction once installed.

(c). Place the splice cable towards the existing cable ensuring the correct colour terminals match.

Brown to Brown
Blue to Blue.

(d). Once cables are in the correct position crimp together.

3 Heat shrink



(a). Slide the heat shrink over the two crimped cables. Ensuring both ends of the heat shrink overlap.

(b). (i) Check the heat shrink is evenly spaced left to right, covering any coloured cables.

(c). (ii) Using a heat gun or blow torch, heat the heat shrink making sure the adhesive glue is released from both sides of the heat shrink all the way round with no gaps.

(d). Ensure the cables are kept straight until the heat shrink has cooled.

(e). Once shrunk down, please ensure there are no splits in the heat shrink.