

MaxiLED Large Globe DMX series Removal and replacement LED Installation Instructions

Product MUST be turned off thoughout this process.

This product must be installed by a qualified electrician in accordance with all national and local electrical and construction codes.



Failure to comply with the installation instructions can result in serious injury or death.

) Removing MaxiLED Globe from festoon



(a). Ensure power is Switch off to the festoon.

(b). Wearing gloves, hold the base of the festoon and the Globe in each hand.



(c). Twisting the globe in an anti-clockwise direction, remove the globe from the festoon.

(d). With the globe removed from the festoon. The grommet must be retained.

Removal of LED connection board



2

(a). Without pulling on the wires, pull on the connection board to remove from the existing festoon.



(b). The connection board should slide out of the festoon housing.

THE GROMET SHOULD NOT BE REMOVED.

3) Replacing NEW LED



4

(a). Find the correct fitting that corresponds to the replacement globe. NOTE Example: Globe 7, to replaced with replacement globe 7.



(b). Place connection board into festoon housing.

(LED IS NOT POLARITY SENSITIVE. I.E.THE LED CAN BE INSERTED EITHER SIDE)

Replacing Globe to the festoon



(a). Check the grommet is secure on the globe neck.

(b). Check the connection board is fully inserted into the festoon housing.

(c). Make sure no cables are loose or trapped in the globe neck.



(d). Visually check the seal has not been trapped and is in good condition. In a clockwise twisting direction, lock and click the globe to the festoon cable.

TWIST THE GLOBE TILL YOU CAN FEEL A 'CLICK' THIS WILL ENSURE A IP68 SEAL.